



SEAL PENETRATIONS IN SMOKE DRAFT CURTAIN AIR TIGHT. SEE ARCH PLANS FOR CONSTRUCTION.

WATER HEATER AND FLUE BY PLUMBER.

MOUNT AIR DOOR IN CEILING, CENTERED ON DOOR OPENING, AT 18" OFF WALL. PROVIDE WITH FACTORY MICROSWITCH CONTROL.

← MEAL DELIVERY CANOPY. SEE ARCHITECTURAL

INSTALL ACCESSORY AIR DIVERTER BOX AT TOP OF TORMAX DOOR OPENING.

INSTALL AIR CURTAIN SO THAT EDGE OF CABINET IS 0'-4" FROM WALL.

FIELD WIRE FACTORY PROVIDED CONTROLS. SEE KITCHEN ELEVATIONS FOR EXACT LOCATION OF SWITCH.

MOUNT AC#1 MAIN TRUNK LINE AS TIGHT AS POSSIBLE TO MINIMIZE LEAKAGE.