



□ INSTALL NEW OWNER-FINISHED TYPE-I KITCHEN HOOD EXHAUST SYSTEM, FIRE SUPPRESSION SYSTEM, AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM. INSTALL HOOD CONTROL, SENSORS, AND HUMIDITY SENSORS WITHIN HOOD CABINET ACCORDING TO MANUFACTURER'S INSTALLATION REQUIREMENTS.