



- 1. INSTALL NEW OWNER-FINISHED TYPE-I KITCHEN HOOD EXHAUST SYSTEM. FIRE SUPPRESS DUCT, AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM. INSTALL HOOD CONTROL SYSTEM (SEE NOTES) WITHIN HOOD UTILITY CABINET ACCORDING TO MANUFACTURER'S INSTALLATION REQUIREMENTS.
- 2. INSTALL NEW OWNER-FINISHED ROOF-MOUNTED EXHAUST FAN. INSTALL 12" GREESE