



[1] INSTALL NEW OWNER-FURNISHED TYPE-I KITCHEN HOOD EXHAUST SYSTEM, FIRE SUPPRESSION DUCT, AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM INSTALL HOOD COVERS TO EXISTING CABINETS AND EQUIPMENT WITHIN HOOD UTILITY CABINET ACCORDING TO INSTALLATION REQUIREMENTS.
 [2] INSTALL 1" NEW OWNER-FURNISHED DRY-PANINER EXHAUST FAN INSTALL 1" DRY-PANINER