



[1] INSTALL NEW OWNER-DESIGNED TYPE-I KITCHEN HOOD EXHAUST SYSTEM, FIRE ALARM EXHAUST SYSTEM, AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM, INSTALL HOOD CONTROLS (SENSORS), AND HANGING SENSORS) WITHIN HOOD CABINET ACCORDING TO INSTALLATION REQUIREMENTS.
 [2] INSTALL NEW OWNER-DESIGNED ROOF-MOUNTED EXHAUST FAN. INSTALL 1" GREASE