



- 1 INSTALL NEW OWNER-FURNISHED TYPE-I KITCHEN HOOD EXHAUST DUCT, AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM (SENSORS AND HUMIDITY SENSORS) WITHIN HOOD UTILITY CLOSET INSTALLATION REQUIREMENTS.
- 2 INSTALL NEW OWNER-FURNISHED ROOF-MOUNTED EXHAUST FAN. EXTEND HOOD COLLAR, BALANCE TO AIRFLOW RATE.