



- 1. INSTALL NEW OWNER-FINISHED TYPE I KITCHEN HOOD EXHAUST SYSTEM. FIRE SUPPRESSED DUCT AND ALL OTHER REQUIREMENTS FOR A TYPE I SYSTEM. INSTALL HOOD CONTROL, FAN(S), AND AIRFLOW SENSOR(S) WITHIN HOOD UTILITY CABINET ACCORDING TO MANUFACTURER'S INSTALLATION REQUIREMENTS.
- 2. INSTALL NEW OWNER-FINISHED ROOF-MOUNTED EXHAUST FAN. INSTALL 12" GROUND DUCT