



□ INSTALL NEW OWNER-FINISHED TYPE I KITCHEN HOOD EXHAUST SYSTEM, FIRE SUPPRESSION, DUCT, AND ALL OTHER REQUIREMENTS FOR A TYPE I SYSTEM. INSTALL HOOD CONTROL FAN(S), SERVO(S), AND HUMIDITY SERVO(S) WITHIN HOOD CABINET ACCORDING TO MANUFACTURER'S INSTALLATION REQUIREMENTS.