



1) INSTALL NEW OWNER-SPECIFIED TYPE-I KITCHEN HOOD EXHAUST SYSTEM, FIRE SAFETY SENSORS, AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM, INSTALL HOOD CONTROL SENSORS, AND HIDDEN SENSORS WITHIN HOOD UTILITY CABINET ACCORDING TO INSTALLATION REQUIREMENTS.