



□ INSTALL NEW OWNER-FURNISHED TYPE-I KITCHEN HOOD DUCT, AND ALL OTHER REQUIREMENTS FOR A TYPE-I SENSOR(S), AND HANDIY SENSOR(S) WITHIN HOOD UT INSTALLATION REQUIREMENTS.