



□ INSTALL NEW OWNER-FINISHED TYPE-I KITCHEN HOOD EXHAUST SYSTEM FIRE SPRINKLER DUCT AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM. INSTALL HOOD CONTROL SENSORS, AND HUMIDITY SENSORS WITHIN HOOD UTILITY CABINET ACCORDING TO THE INSTALLATION REQUIREMENTS.

□ INSTALL NEW AMBER-LENSED DIFFUSE-WHITEN PULVEREALY INSTALL 1" OFFSET