



□ INSTALL NEW OWNER-FINISHED TYPE-I KITCHEN HOOD EXHAUST SYSTEM, FIRE SUPPRESSION SYSTEM, GREASE DUCT, AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM. INSTALL HOOD CONTROL PANEL, TEMPERATURE SENSORS, AND INFLUITY SENSORS WITHIN HOOD UTILITY CABINET ACCORDING TO MANUFACTURERS INSTALLATION REQUIREMENTS.

[ ] INSTALL NEW OWNER-FINISHED BOVE-MOUNTED EXHAUST FAN. INSTALL 1" AIRSPACE TRIT TO BOVE-MOUNTED