



□ INSTALL NEW OWNER-FURNISHED TYPE-I KITCHEN HOOD EXHAUST DUCT AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM (SENSORS, AND HANDIY SENSORS) WITHIN HOOD UTILITY & INSTALLATION REQUIREMENTS.