

MECHANICAL FLOOR PLAN

MEAL DELIVERY CANOPY, SEE ARCHITECTURAL.

INSTALL ACCESSORY AIR DIVERTER BOX AT TOP OF FORMAL DORM OPENING.

INSTALL AIR CURTAIN SOCKET IS 0-4 FROM WALL.

FIELD WIRE FACTORY PROVIDED CONTROLS FOR EXACT LOCATION OF SWITCH.

LOCATE BOTTOM OF HEATER FRAME 12" AFF.

MOUNT AC41 MAIN TRUNK LINE AS TIGHT AS POSSIBLE TO STRUCTURE.

WATER HEATER AND FUEL BY PLUMBER.

CEILING MOUNTED RECYCLING PLATING FAN DISCHARGE ABOVE CEILING.

SEAL PENETRATIONS IN SMOKE DRAFT CURTAIN AIR TIGHT. SEE ARCH PLANS FOR CONSTRUCTION.

TO AC43 SENSOR #2 SEE 21M-501.

