



□ INSTALL NEW OWNER-FURNISHED TYPICAL KITCHEN HOOD EXHAUST SYSTEM FIRE SUPPRESSION DUCT, AND ALL OTHER REQUIREMENTS FOR A TYPICAL SYSTEM, INSTALL HOOD CONTROL SENSORS, AND HANDY SENSORS WITHIN HOOD UTILITY CABINET ACCORDING TO INSTALLATION REQUIREMENTS.