



□ INSTALL NEW OWNER-FINISHED TYPE-I KITCHEN HOOD EXHAUST SYSTEM FIRE SMOKE DETECT AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM. INSTALL HOOD CONTROLS (SENSORS) AND LAMPITY (SENSORS) WITHIN HOOD UTILITY CABINET ACCORDING TO INSTALLATION REQUIREMENTS.

□ INSTALL NEW OWNER-FINISHED PHOTO EYE DETECTORS WITHIN HOOD UTILITY CABINET ACCORDING TO INSTALLATION REQUIREMENTS.