



□ INSTALL NEW OWNER-FURNISHED TYPE-I KITCHEN HOOD EXHAUST DUCT AND ALL OTHER REQUIREMENTS FOR A TYPE-I SYSTEM (SENSORS, AND FLOWMETER SENSORS) WITH HOOD UTILITIES INSTALLATION REQUIREMENTS.