



□ INSTALL NEW OWNER-FURNISHED TFE-1 KITCHEN HOOD EXHAUST SYSTEM FIRE ALARM DUCT AND ALL OTHER REQUIREMENTS FOR A TFE-1 SYSTEM. INSTALL HOOD CONTROL SENSORS AND HANDIPLY SENSORS (WITHIN HOOD UTILITY CABINET ACCORDING TO INSTALLATION REQUIREMENTS).