



□ INSTALL VIBRATION DAMPENING FEET TO KITCHEN HOOD UNITS AND ALL OTHER REQUIREMENTS FOR A TYPE I SYSTEM SENSORS, AND HANDY SENSORS) WITHIN HOOD UNTIL INSTALLATION REQUIREMENTS.